

Model Development Phase Template

Date	25 September 2024
Team ID	739698
Project Title	Strain analysis based on eye blinking
Maximum Marks	10 Marks

Initial Model Training Code, Model Validation and Evaluation Report

The initial model training code will be showcased in the future through a screenshot. The model validation and evaluation report will include a summary and training and validation performance metrics for multiple models, presented through respective screenshots.

Initial Model Training Code (5 marks):

```
D:\Strain Analysis GCH\Flask\GCH.py
templates X predict.html X modelbuilding.py X index.html - D:\...templates X app.py - D:\...Flask X blink_count.py X app_gm.py X app.py - D:\...Flask X GCH.py X
1 from scipy.spatial import distance as dist
2 from imutils.video import FileVideoStream
3 from imutils.video import VideoStream
4 from imutils import face_utils
5 import numpy as np
6 import argparse
7 import imutils
8 import time
9 import dlib
10 import cv2
11 import datetime
12 from gtts import gTTS
13 import tkinter as tk
14 from tkinter import ttk
15 from playsound import playsound
16
17 def playaudio(text):
18     speech = gTTS(text)
19     print(type(speech))
20     speech.save("../output1.mp3")
21     playsound("../output1.mp3")
22     return
23
24
25 LARGE_FONT = ("Verdana",12)
26 NORM_FONT = ("Helvetica",10)
27 LARGE_FONT = ("Helvetica",8)
28
29 def popupmsg(msg):
30
31     popup = tk.Tk()
32
33     popup.wm_title("Urgent")
34
35     style = ttk.Style(popup)
36
37     style.theme_use('classic')
38
39     style.configure('Test.TLabel', background= 'aqua')
40     label = ttk.Label (popup, text=msg,style= 'Test.TLabel')
```

conda: base (Python 3.12.7)

```
.\templates X predict.html X modelbuilding.py X index.html - D:\...\templates X app.py - D:\...\Flask X blink_count.py X app_gm.py X app.py - D:\...\Flask X GCH.py X
39 style.configure('Test.TLabel', background= 'aqua')
40 label = ttk.Label (popup, text=msg,style= 'Test.TLabel')
41
42 label.pack(side="top", fill="x", pady=10)
43
44 B1 = ttk.Button (popup, text="Okay", command = popup.destroy).pack()
45
46 popup.mainloop()
47
48
49 def eye_aspect_ratio(eye):
50
51     #compute the euclidean distances between the two sets of # vertical eye landmarks (x, y)-coordinates
52
53     A = dist.euclidean (eye [1], eye[5])
54
55     B = dist.euclidean (eye [2], eye[4])
56
57     # compute the euclidean distance between the horizontal
58
59     # eye landmark (x, y)-coordinates
60
61     C= dist.euclidean (eye[0], eye[3]) # compute the eye aspect ratio
62
63     ear = (A + B) / (2.0 * C)
64
65     # return the eye aspect ratio
66
67     return ear
68
69 # construct the argument parse and parse the arguments
70
71 ap = argparse.ArgumentParser()
72
73 ap.add_argument("-p", "--shape_predictor", required=True, help="path to facial landmark predictor")
74
75 ap.add_argument("-v", "--video", type=str, default="", help="path to input video file")
76
77 args = vars (ap.parse_args())
78
```

```
D:\Strain Analysis GCH\Flask\GCH.py
templates X predict.html X modelbuilding.py X index.html - D:\...templates X app.py - D:\...Flask X blink_count.py X app_gm.py X app.py - D:\...Flask X GCH.py X
79 def eye_blink():
80     EYE_AR_THRESH = 0.3
81     EYE_AR_CONSEC_FRAMES = 3
82
83
84     COUNTER = 0
85     TOTAL = 0
86     print("[INFO] Loading facial landmark predictor...")
87     detector = dlib.get_frontal_face_detector()
88     predictor = dlib.shape_predictor(args['shape_predictor'])
89
90     #predictor =dlib.shape_predictor(args['shape_predictor'])
91     #predictor = dlib.shape_predictor(args['shape_predictor'])
92     print(type(predictor),predictor)
93
94     (lStart, lEnd) = face_utils.FACIAL_LANDMARKS_IDXS["left_eye"]
95     (rStart, rEnd) = face_utils.FACIAL_LANDMARKS_IDXS["right_eye"]
96
97
98     eye_thresh = 10
99     before = datetime.datetime.now().minute
100
101     if not args.get("video", False):
102         print("[INFO] starting video stream..")
103         vs = VideoStream(src = 0).start()
104         time.sleep(1.0)
105     else:
106         print("[INFO] Opening video file...")
107         vs = cv2.VideoCapture(args["video"])
108         time.sleep(1.0)
109
110     while True:
111         frame = vs.read()
112         if frame is None:
113             print("unable to capture")
114             break
115         frame = imutils.resize(frame, width=450)
116         gray = cv2.cvtColor(frame, cv2.COLOR_BGR2GRAY)
117         rects = detector(gray, 0)
```

```
D:\Strain Analysis GCH\Flask\GCH.py
templates X predict.html X modelbuilding.py X index.html - D:\...templates X app.py - D:\...Flask X blink_count.py X app_gm.py X app.py - D:\...Flask X GCH.py X
116 frame = imutils.resize(frame, width=450)
117 gray = cv2.cvtColor(frame, cv2.COLOR_BGR2GRAY)
118 rects = detector(gray, 0)
119 for rect in rects:
120     shape = predictor(gray, rect)
121     if shape is None:
122         print("shape predictor returning none")
123         continue
124     shape = face_utils.shape_to_np(shape)
125     leftEye = shape[lStart:lEnd]
126     rightEye = shape[rStart:rEnd]
127     leftEAR = eye_aspect_ratio(leftEye)
128     rightEAR = eye_aspect_ratio(rightEye)
129
130     ear = (leftEAR + rightEAR) / 2.0
131
132     leftEyeHull = cv2.convexHull(leftEye)
133     rightEyeHull = cv2.convexHull(rightEye)
134     cv2.drawContours(frame, [leftEyeHull], -1, (0,255,0),1)
135     cv2.drawContours(frame, [rightEyeHull], -1, (0,255,0),1)
136
137     if ear < EYE_AR_THRESH:
138         COUNTER+= 1
139
140     else:
141         if COUNTER >= EYE_AR_CONSEC_FRAMES:
142             TOTAL+= 1
143         COUNTER = 0
144
145     now = datetime.datetime.now().minute
146     no_of_min = now - before
147     print(no_of_min, before, now)
148     blinks = no_of_min * eye_thresh
149
150     if(TOTAL < blinks-eye_thresh):
151         playsound("Take rest for a while as yourblink count is less than average")
152         popupmsg("Take rest for a while!!!! :D")
153         cv2.putText(frame, "Take rest for a while!!!! :D", (70,150),cv2.FONT_HERSHEY_SIMPLEX, 0.7, (0,0,255),2)
154
155     elif (TOTAL > blinks + eye_thresh):
156         playsound("Take rest for a while as yourblink count is more than average")
```

```

D:\Strain Analysis GCH\Flask\GCH.py
templates X predict.html X modelbuilding.py X index.html - D:\...\templates X app.py - D:\...\Flask X blink_count.py X app_gm.py X app.py - D:\...\Flask X GCH.py X
136
137     if ear < EYE_AR_THRESH:
138         COUNTER+= 1
139
140     else:
141         if COUNTER >= EYE_AR_CONSEC_FRAMES:
142             TOTAL+= 1
143             COUNTER = 0
144         now = datetime.datetime().now().minute
145         no_of_min = now - before
146         print(no_of_min, before, now)
147         blinks = no_of_min * eye_thresh
148
149     if(TOTAL < blinks-eye_thresh):
150         playsound("Take rest for a while as yourblink count is less than average")
151         popupmsg("Take rest for a while!!!! :D")
152         cv2.putText(frame, "Take rest for a while!!!! :D", (70,150),cv2.FONT_HERSHEY_SIMPLEX, 0.7, (0,0,255),2)
153
154     elif (TOTAL > blinks + eye_thresh):
155         playsound("Take rest for a while as yourblink count is more than average")
156         popupmsg("Take rest for a while!!!! :D")
157         cv2.putText(frame, "Take rest for a while!!!! :D", (70,150),cv2.FONT_HERSHEY_SIMPLEX, 0.7, (0,0,255),2)
158
159     cv2.putText(frame, "Blinks: {}".format(TOTAL),(10,30),cv2.FONT_HERSHEY_SIMPLEX, 0.7, (0,0,255),2)
160
161     cv2.putText(frame, "Ear: {:.2f}".format(ear),(300,30),cv2.FONT_HERSHEY_SIMPLEX, 0.7, (0,0,255),2)
162
163     cv2.imshow("Frame", frame)
164     key = cv2.waitKey(1) & 0xFF
165     if key == ord('q'):
166         break
167
168     cv2.destroyAllWindows()
169
170     vs.stop()
171
172
173
174

```

Model Validation and Evaluation Report (5 marks):

Model	Summary	Training and Validation Performance Metrics
Model 1	Screenshot of the neural network summary	-

Model 2	Screenshot of the neural network summary	-
...